



ADS-THR-GM2/7/10

GM2: Factory fit installation T-harness for select GM 'SWC' models 2004 to 2012. Plugs directly into vehicle factory connectors with little-to-no analog connections required. Compatible with iDataStart HCX control module.

GM7: Factory fit installation T-harness for select GM 'flip-key' and standard key models 2010 and up. Plugs directly into vehicle factory connectors with little-to-no analog connections required. Compatible with iDataStart HCX control module.
(GM12 replacement coming soon!)

GM10: Factory fit installation T-harness for select GM 'SWC' full-size models 2006 and up. Plugs directly into vehicle factory connectors with little-to-no analog connections required. Compatible with iDataStart HCX control module.

T-HARNESSES AT-A-GLANCE

iDataStart systems offer a wide range of T-harnesses designed to plug directly into vehicle factory connectors, with little to no wire splicing required. Ask your installer to see if a T-harness is available for your vehicle.

VEHICLE MAKES	T-HARNESSES
UNIVERSAL	ADS-AHR-HCX
	ADS-THR-GM2, ADS-THR-GM7 ADS-THR-GM10
	ADS-THR-F01, ADS-THR-FM8
	ADS-THR-CH4, ADS-THR-CH5, ADS-THR-CH10
	ADS-THR-HA2, ADS-THR-HA3, ADS-THR-HA6, ADS-THR-HA7, ADS-THR-HA8
	ADS-THR-MA3
	ADS-THR-NI3, ADS-THR-NI4, ADS-THR-NI5
	ADS-THR-TL5, ADS-THR-TL7
	ADS-THR-AU1, ADS-THR-AU2, ADS-THR-VW1